



PROJECT AI CARE 技術白皮書

AI Box Hands-on Lab Guide

Building Your Own Device for
AI Care with Azure AI & IoT Services

Tommy Wu

IoT Solution Architect Microsoft

目錄

1	Background and Challenge	2
2	Solution Overview	2
3	AI CARE Device Hardware Architecture	2
4	AI CARE System Architecture	4
5	Hands-On Guide Tutorial.....	6
5.1	M5StackCore	6
5.2	ESP32 CAM	7
5.3	Battery.....	8
5.4	Mask Training with Azure Custom Vision	9
5.5	Edge Computing with Azure IoT Edge.....	10
5.6	Power BI Dashboard.....	12
5.7	IoT Device Control and Monitoring on IoT Central	13
5.8	(To-Do) Azure BOT service integration	15
6	Demo Video Reference –.....	16
6.1	AI Care Edge Demo -.....	16
6.2	AI Care Device hands-on -	16
6.3	Mask Training by Custom Vision -	16
6.4	Mask Inference Demo with Custom Vision on IoT Edge -	16
7	Feedback.....	16

1 Background and Challenge –

- Increased chance of people contact for 1st line security guards
- Increased labor time and cost: 8~10 hours per day standing there
- Efficiency on peak hours will be challenging
-


2 Solution Overview –

Idea - An easy-to-adopt AIoT Technology to help real estate building management companies save labor and decrease chance of contact for 1st line security guard in difficult time

- Client Device – Azure Certified Device and Sensors (Thermal/Camera)
- Backend – Azure AI and IoT Services
 - Azure Custom Vision
 - Azure IoT Central
 - Azure IoT Edge
 - Azure Event Hub
 - Power BI
 - Cosmos DB (Optional)
 - Azure Stream Analytics (Optional)

3 AI CARE Device Hardware Architecture –

Hardware Architecture




- Main Controller – M5Stack Core –
 - Azure Certified Device
 - Wifi built-in
 - Azure IoT SDK
 - Thermal Data Collection
 - Arduino compatible
 - Real-time thermal display
 - 150 mah Battery

- Sensors –
 - Thermal Camera (AMG 8833) –
 - ◆ I2C m5stack connected.
 - ◆ 8x8 array of IR thermal sensors.
 - ◆ Up to 7 meters (23) feet.
 - ◆ Maximum frame rate of 10Hz

 - Camera (ESP 32 Cam)–
 - ◆ WIFI built-in
 - ◆ MPEG Video Streaming
 - ◆ AI Detection
 - ◆ Leverage Azure Custom vision AI.

- Battery – Extra 3.7v 2000 mah
- Card Box Layout –




Internal Wired -



4 AI CARE System Architecture –

System Overview



1 Mask Training –

1. Leverage Azure Custom Vision for mask training in 5 minutes !
2. Re-train your own dataset to improve your enterprise accuracy.
3. Deploy AI model as IoT Edge module for quick deployment & distribution.

2 IoT Edge –

1. AI on Edge for inference performance and data consolidation.
2. Edge dashboard module for real-time result display.
3. Large Scale AI Module deployment efficiency.

3 IoT Central –

1. Overall Coronavirus Epidemic prevention dashboard
2. Create Your Cross multi-region Summary in 5 mins
3. Control Sensor device settings and monitoring easily
4. Notification built-in and quick customization.

4 BoT Service –

1. Connect to social media notification (Line/Facebook/SMS..etc)
2. Create your own logic for notification dispatching

5 Power BI + CosmosDB –

1. Enterprise Dashboard for your deep customization UI requirement.
2. Develop your enterprise level dashboard based on IoT Central dataset
3. Quick widgets and drag&drop mode to mash up your complex UI and reporting.

5 Hands-On Guide Tutorial -


● Device Side –

5.1 M5StackCore –

5.1.1 Development & Pinout Reference –

https://docs.m5stack.com/#/en/quick_start/m5core/m5stack_core_get_started_Arduino_Windows

5.1.2 Git clone from - <https://github.com/tommywu052/project-AICARE.git>




5.1.3 Go to project-AICARE/device/**M5Stack_Thermal**/, modify the code as below for your own wifi ssid / password and Azure IoT Central device connection string.

```
155// Please input the SSID and password of WiFi.
156const char* ssid = "YourWiFiSSID";
157const char* password = "YourWiFiPassword";
158
159// Please input connection string of the form "HostName=<host_name>;DeviceId=<device_id>;SharedAccessKey=<device_key>" from IoT Central
160static const char* connection_string = "Your Connection String from IoT Central Connect Settings";
```

5.1.4 Flash the modified .ino file into your m5stack core . make sure you have import the related library as m5stack core reference document as step 1.



5.1.5 Port Connection map



5.2 ESP32 CAM –

- Development & Pinout Reference – <https://www.instructables.com/id/ESP-32-Camera-Streaming-Video-Over-WiFi-Getting-St/>
- ESP32 CAM connect M5stack map –




5.3 Battery –

5.3.1 External Battery Pinout map –



● Backend Side –


5.4 Mask Training with Azure Custom Vision –




5.4.1 Download Kiosk App : <http://aka.ms/kioskapp>

5.4.2 Setting your training & prediction key in kiosk app from <https://www.customvision.ai/> website.

In Custom Vision Website Keys -



In Kiosk App Settings –




5.4.3 Mask Training Steps with Custom Vision AI –

- Leverage Azure Custom Vision for mask training in 5 minutes !
- Add Common Images by Bing Search Engine.
- Add Your own mask training images with camera or local images to improve accuracy.
- One-click training and export AI model for real-time testing
- Deploy as IoT Edge module for scale deployment.

5.5 Edge Computing with Azure IoT Edge -

- Web service over HTTP running locally that takes in images and classifies them based on a custom model built via the Custom Vision
- Can be deployed and configured via Cloud
- Can leverage Edge device like GPU/VPU/FPGA to improve the inference
- Adapt to different acceleration framework like OpenVINO, CUDA , DeepStream, ONNXRT and etc.



5.5.1 Refer the document

<https://github.com/Azure-Samples/Custom-vision-service-iot-edge-raspberry-pi/tree/master/> for IoT Edge setup, remember to choose amd64 for x64 platform.


5.5.2 Install the node-red IoT Edge module as -

<https://github.com/iotblackbelt/noderededge module>

5.5.3 Import the code from

<https://github.com/tommywu052/project-AICARE/blob/master/backe>

[nd/IoTEdge/AICare-nodered-flows.json](#) into your node-red edge.



Review Your UI widget as <http://localhost:yourport/ui>



5.5.4 Export Custom vision model as IoT Edge and copy **model.pb** and **labels.txt** from the zip file into docker images via docker cp.

docker images

REPOSITORY			TAG
IMAGE ID	CREATED	SIZE	
a9publicregistry.azurecr.io/imageclassification			0.3.8-maskai

0be0b6d56941 2 days ago 1.57GB

docker cp model.pb 0be0b6d56941:/app/model/model.pb

docker cp labels.txt 0be0b6d56941:/app/model/labels.txt

5.5.5 Get the inference code from -

<https://github.com/tommywu052/project-AICARE/blob/master/backup/IoTEdge/yolocv-public.py>

Modify the code - line 22-24 as your device key on IoT Central :

```

21 #iot central initialize
22 deviceId = "your device id on iot central"
23 scopeId = "iot central scope id"
24 mkey = "SAS Key on IoT Central"

```

Modify the code – line 63 as your image inference host at 5.5.1 step

```
63 IMAGE_PROCESSING_ENDPOINT = 'http://localhost:8081/classify/helmets'
```

Modify the code – line 261 as your ESP32 CAM streaming IP

(ex:192.168.43.138, port 81 is default MJPEG streaming)

```
261 url="http://192.168.43.138:81/stream"
```

5.6 Power BI Dashboard -

- In few clicks, you can set up an end-to-end solution that pulls exported Edge measurements, devices, and device templates data from IoT Central
- Power BI Solution for creates the data pipeline in your IoT Central that brings data from your Azure Event Hub




5.6.1 Refer the document for Real-Time Streaming –

<https://docs.microsoft.com/zh-tw/power-bi/service-real-time-streaming>


5.6.2 Add Real-Time widget with Web Content and Streaming data set -

<https://docs.microsoft.com/zh-tw/power-bi/service-dashboard-add-widget>





5.6.3 Note – Data on real-time dashboard is coming from IoT Central export as Azure Event Hubs-



5.7 IoT Device Control and Monitoring on IoT Central -

- Summary Dashboard - Data from Thermal/Camera Sensors and Alert Notification Triggered
- Device Control & Monitoring through command/settings pages



5.7.1 Refer the document to Create Your IoT Central Dashboard Application

<https://docs.microsoft.com/zh-tw/azure/iot-central/core/quick-deploy-iot-central>

5.7.2 Device Configuration –

Configure your device telemetry/settings/command/triggers on the device template (mapping the code on the device side Arduino and python code)

裝置範本
thermal (1.1.0)

度量 設定 屬性 命令 規則 儀表板

程式庫

12 號碼

文字

日期

切換

標籤


Enable/Disable Alert ⓘ
true
沒有更新 自 1 分鐘 前起

Temperature Alert Value (°C)
37.3
已同步 自 2 分鐘 前起

Warning Message
Please wait for next validation check
沒有更新 自 0 分鐘 前起

5.7.3 Enable Alert Notification –

<https://docs.microsoft.com/zh-tw/azure/iot-central/core/quick-config-ure-rules>



5.7.4 If you just want to copy my existing application template quickly ,
Please create your application based my share template, click the
below -

<https://apps.azureiotcentral.com/build/new/7490af0a-4e9c-4b54-b7a6-bd0c6092e522>


5.8 (To-Do) Azure BOT service integration –

- Real-time notification for multiple social media channels (LINE/FB/..).
- Integrate speech service for interactive notification.
- No-Code for channels integration.
- Flexible and Extensible

名稱	健康	已發佈	
Direct Line	跑步	--	編輯
Facebook Messenger	跑步	--	編輯
Web Chat	跑步	--	編輯

取得機器人內嵌程式碼

Add a featured channel



More channels



Check this for more detail notification -

<https://docs.microsoft.com/zh-tw/azure/bot-service/bot-builder-tutorial-basic-deploy?view=azure-bot-service-4.0&tabs=csharp>

LINE Integration -

<https://docs.microsoft.com/zh-tw/azure/bot-service/bot-service-channel-connect-line?view=azure-bot-service-4.0>

6 **Demo Video Reference –**

- 6.1 AI Care Edge Demo - https://youtu.be/Wh_21go4Thg
- 6.2 AI Care Device hands-on - <https://youtu.be/d4HgonLCNmM>
- 6.3 Mask Training by Custom Vision - <https://youtu.be/eEb9vfvgW0g>
- 6.4 Mask Inference Demo with Custom Vision on IoT Edge -
<https://youtu.be/dXDriffeE6Q>

7 **Feedback -**

Welcome and Improve the code based on your advanced requirement .Please contact towu@microsoft.com or submit request on the github. Thanks !